



5 Button Keyfob User Guide

Keyfob is a portable remote arming device that allows local control of the alarm system. The buttons can be configured to arm, disarm, trigger panic alarms, or control home automation functions.

Features

- Secure encrypted wireless transmission
- Simple 1 button arming and disarming
- Emergency panic button feature
- Low battery indication
- 3 year warranty

Enroll by sending an enrollment signal from the Keyfob with the help of an installation specialist

Option for sending an enrollment signal

- Press and hold the away and stay arming buttons simultaneously

Operate by pressing the desired button until the LED illuminates

Arm Away Button - Arm in away mode

Arm Stay Button - Arm in stay mode

Disarm Button - Disarm

Light Bulb Button - Custom programmable



Star Button - Custom programmable

Away + Stay Button - Press and hold simultaneously to send police panic (panic alarm triggered from a keyfob cannot be cancelled from same keyfob)

The configuration of the buttons can be customized with the help of an installation specialist

Pro Tips

To replace the battery remove the screw on the back of the fob and unsnap the back from the cover. Replace battery and reattach back cover.



Specifications

Physical	
Housing Dimension	2.2 x 1.5 x .6 inches (5.6 X 3.8 X 1.4 cm)
Weight with Battery	0.8 ounces (23 grams)
Environmental	
Operating Temperature	32 to 120 °F (0 to 49 °C)
Maximum Humidity	85% non-condensing relative humidity
Sensor Specifications	
Frequency	433.92 MHz
Replacement Battery	One Panasonic CR2032
Nominal Battery Life	5 years, depending on usage
Transmitted Indications	Low Battery

Specifications subject to change without notice



5 BUTTON KEYFOB – 010

Tech Support:

1-855-76-THINK

(1-855-768-4465)

www.thinkprotection.com